



CUT LIST for HOW TO INSTALL A SECRET SWINGING DOOR

1/2x8 poplar side stiles. Cut to fit.

1/2x6 poplar baseboards. Cut to fit.

1/2x4 poplar rails and center stile. Cut to fit.

If you're building this project in an existing doorway, you'll first need to deal with any door stops to allow the door to swing in both directions. To remove stops on a site-built jamb, score along each stop with a utility knife and use a pry bar to remove it. Stops on factory-made jambs aren't easily removed, so instead use 1/2-inch-thick furring strips to pad out the jamb on either side of the stop, then simply buy a narrower door to fit. Either way, make sure to fill any gaps or cracks with wood filler and sand the jamb smooth before beginning the project.