

CUT LIST TO BUILD A DECORATIVE DRIVEWAY MARKER

Center Post: Pressure-treated or cedar 6x6: one @ 28 inches

End Posts: Pressure-treated or cedar 4x4: two @ 16 inches

Bottom Rails: Pressure-treated or cedar 1x4: one @ 37 3/4 inches; one @ 37 inches to butt into the first rail

Top Rails: Pressure-treated or cedar 1x4: two @ 48 inches. Cut an 8-footer in half; once installed, flush-cut the tails to length.

Balusters: Pressure-treated or cedar 1x3: eight @ 20 1/2 inches and eight @ 15 inches

Rod: 1/2-inch galvanized-steel rod: one @ 18 inches

CENTER-POST LAYOUT

Decorative Notch: Starting from the top of the post, make a horizontal line all around the post at these intervals: 1 inch, 3 inches, 4 inches, 5 1/2 inches, and 6 1/2 inches.

Vertical Notch:

1 1/2 x 1 1/2 x 20 inches

Measure and mark a cutline 1 1/2 inches into the two faces of one corner, extending 20 inches from the bottom edge of the post.

TIP: If you need to level the marker, use rods on all three posts. Thread a nut and a washer onto the rods, and turn the nuts to adjust the height of the posts.